



**SECURITY**

ASHTRAY IS SECURED WITH VINYL COATED GALVANIZED STEEL AIRCRAFT CABLE. CABLE IS LOOPED AROUND WELDED IN PLACE ATTACHMENT BRACKET AND CRIMPED IN PLACE.

INSTALLATION: \*GENERAL RULE OF THUMB: PICK, PLACE, LEVEL, & ANCHOR.\*

1. USE SPECIAL CARE WHEN POSITIONING TO NOT DAMAGE THE FINISH OF THE ASH URN. DO NOT ROLL ON SIDE, BASE RING, OR FEET. PICK AND SET INTO POSITION.
2. IT IS NOT RECOMMENDED TO LOCATE ANCHOR BOLTS UNTIL ASH URN IS IN PLACE. THIS PRODUCT MUST BE PERMANENTLY AFFIXED TO THE GROUND. CONSULT YOUR LOCAL CODES FOR REGULATIONS.
3. ONCE ANCHOR BOLT(S) ARE IN PLACE, REPLACE ASH URN IN POSITION AND USE LEVELING FEET TO LEVEL.
4. ANCHOR BOLT(S) NOT PROVIDED BY FLORENCE.
5. IT IS IMPORTANT TO REMEMBER TO PICK AND SET ASH URN INTO POSITION. THIS IS TO PROTECT THE FINISH AND LONGEVITY OF THE ASH URN.

**NOTES:**

1. DRAWINGS NOT TO SCALE. DO NOT SCALE DRAWINGS.
2. THIS PRODUCT IS SHIPPED FULLY ASSEMBLED.

**PACKAGING SIZE: 19" x 19" x 32"**  
**SHIPPING WEIGHT: 90 LBS**

