



PACKAGING SIZES: 38" x 64" x 11"
 TOTAL SHIPPING WEIGHT: 100 LBS

PREPERATION:

1. REMOVE BIKE RACK FROM ITS BOX AND BAGS, AND PLACE ON TOWELS OR OTHER SOFT SURFACE TO PREVENT SCRATCHING (TOWELS, CARDBOARD, GRASS, ECT.)

INSTALLATION: *SURFACE MOUNT*

1. USE SPECIAL CARE WHEN POSITIONING TO NOT DAMAGE THE FINISH OF THE BIKE RACK. PICK AND SET INTO POSITION.
2. IT IS NOT RECOMMENDED TO LOCATE ANCHOR BOLTS UNTIL BIKE RACK IS IN PLACE. THIS PRODUCT MUST BE PERMANENTLY AFFIXED TO THE GROUND. CONSULT YOUR LOCAL CODES FOR REGULATIONS.
3. ONCE ANCHOR BOLT(S) ARE IN PLACE, REPLACE BIKE RACK IN POSITION.
4. ANCHOR BOLT(S) NOT PROVIDED BY FLORENCE.
5. IT IS IMPORTANT TO REMEMBER TO PICK AND SET BIKE RACK INTO POSITION. THIS IS TO PROTECT THE FINISH AND LONGEVITY OF THE BIKE RACK.

NOTES:

1. DRAWINGS NOT TO SCALE. DO NOT SCALE DRAWINGS.
2. THIS PRODUCT IS SHIPPED FULLY ASSEMBLED.

